



## Satellite tracker

### 1. SWITCHING ON.

Press and hold the “POWER” button for at least 5 sec, until the indicator light above starts to flash frequently. Then release the button – the indicator will flash 1pulse per second.

### 2. TRACKING.

Press and hold the “TRACKING” button for at least 5 sec, until the indicator light starts to flash frequently. Then release the button – the indicator will flash 1pulse per second. The device starts send the pulses to the monitoring server.

### 3. MESSAGE OK.

**Sending the message about the retire due to technical reasons. The crew is OK.**

Press and hold the “Message OK” button for at least 5 sec, until the indicator light comes on. Then release the button – the indicator will flash 1pulse per second. Your “OK” message will be received by the rally HQ.

### 4. SOS. Medical assistance needed.

Shift the lock of the SOS button, to the lefthand side.

Press and hold the “SOS” button for at least 5 sec, until the indicator light comes on. Then release the button – the indicator will flash 1pulse per second. Your “SOS” message will be received by the rally HQ.

**TO BE USED ONLY for extraordinary call for medical assistance for the competitor.**